

## STEP BY STEP PROGRAMMING OF THE TH111

The TH111 is a 7-day independent programmable thermostat allowing you to program 4 settings/day. Please select your preference from the 4 options below and proceed with the steps as mentioned.

1. If you would like to have the same temperature for 24 hrs – then you will have to follow steps 1 - 3.
2. If you would like 2 settings/day, then you will have to follow steps 1, 2 and 4(a, b, c and f).
3. If you would like 3 settings/day, then you will have to follow steps 1, 2 and 4 (a, b, c, d and f).
4. If you would like 4 settings/day programmed into your thermostat, then follow steps 1, 2 and 4 (a-f).

### 1. If the power has been applied for the first time :

- Set the current time by using the hour and minute buttons
- Set the day by using the Day button

### 2. These settings represent the temperatures you wish to have


During the day or when the heating is required-Comfort temperature ☼ (select the Comfort temperature by pressing the ☼ button then use the arrow keys to select the temperature you require. Finally press and hold the ☼ button for approx 3 secs until the ☼ icon is displayed).

Your comfort temperature is \_\_\_\_ °C.



At night or when the heating is not required - Economy temperature ☾ (select the Economy temperature by pressing the ☾ button then use the arrow keys to select the temperature you require. Finally press and hold the ☾ button for approx 3 secs until the ☾ icon is displayed).

Your economy temperature is \_\_\_\_ °C






### 3. If you require the same temperature (only one temperature setting) for 24 hrs then:


- Press Mode button until it displays the manual Ⓜ icon
- Press the arrow keys ▲▼ for the temperature you require



Or

you can set it in the following way by selecting either the comfort or economy temperatures programmed earlier.









- Select the mode button until it displays the manual  icon
- Select either the comfort  or economy  button for the comfort or economy temperatures, whichever may be preferred.



**4. If you require more than one temperature setting, then follow the steps detailed below:**









The TH115 allows you to program 4 different settings for each day of the week

For eg

The time at which you wake up	P1		
The time you leave (eg for work)	P2		
The time you arrive back home	P3		
The time you go to bed	P4		




**a) Use this grid to note down your time settings for the week:**

Prog	Setpoint	MO	TU	WE	TH	FR	SA	SU
P1 								
P2 								
P3 								
P4 								


**b) Now set P1 ()**

- Press PGM to access the programming mode
- Select Day – for the day to be programmed (if you require the same time on all days of the week, press and hold the Day button for 3 secs)
- PGM to select the program – in this case P1
- Hour and Min buttons to set the time
- Mode/Ret to exit this function.




**c) Now set P2 (🏠👉👉)**

- Press PGM to access the programming mode
- Select Day – for the day to be programmed (if you require the same time on all days of the week, press and hold the Day button for 3 secs)
- PGM to select the program – in this case P2
- Hour and Min buttons to set the time
- Mode/Ret to exit this function




**d) If you require 3 settings/day, set P3 (🏠👉👉👉)** as below:

- Press PGM to access the programming mode
- Select Day – for the day to be programmed (if you require the same time on all days of the week, press and hold the Day button for 3 secs)
- PGM to select the program – in this case P3
- Hour and Min buttons to set the time
- Mode/Ret to exit this function



**e) If you require 4 settings/day, set P4 (🏠👉👉👉👉)** as below:

- Press PGM to access the programming mode
- Select Day – for the day to be programmed (if you require the same time on all days of the week, press and hold the Day button for 3 secs)
- PGM to select the program – in this case P4
- Hour and Min buttons to set the time
- Mode/Ret to exit this function



**f) Finally to access the automatic ⌚ mode**

- Press the Mode button until it displays the automatic ⌚ icon
- The comfort 🌞 or economy 🌙 temperatures being used will be shown
- The current program no. 🏠👉, 🏠👉👉, 🏠👉👉👉 or 🏠👉👉👉👉 will also be shown.

Note : It is faster to program the same schedule for the entire week and then modify the exception days eg weekends – Sat & Sun

If your Sat & Sun schedules are different from the rest of the week then

- Press on Day button until SA or SU is displayed
- Press on PGM to select the respective program i.e. P1, P2, P3 or P4 (where you require to change the time)

Eg if you wish to change the times for P1 and P2 and need to clear the times for P3 and P4

Select P1 and change the time using the Hour and Min buttons


Select P2 and change the time as above

Select P3 and press the clear button to erase it

Select P4 and press the clear button to erase it

- Mode/Ret to exit this function

Once you have completed the schedule for Saturday, you can repeat the schedule for Sunday.



### Points to note

If you are going to be away for an extended period then select your vacation temperature by :

- Pressing on the \* and ⏪ buttons at the same time
- Using the arrow keys select your preferred vacation temperature
- Then press and hold the \* and ⏪ buttons simultaneously for approx 3 secs until the button until the vacation icon is displayed

Your vacation temperature is \_\_\_\_\_ °C

You can return to the normal operating mode by pressing the Mode button.

If you wish to return to the programmed settings, press on the Mode button twice.

\*\* To erase your program press

- PGM (to select the program to be erased)
- Day (to select the day)
- Clear

The time field will display --:-- which means that the selected program is inactive.

While you are in Automatic mode, you can temporarily modify the room temperature by:

- Pressing the arrow keys to select the desired temperature
- Then press on the \* and ⏪ buttons to select the Comfort or Economy settings which have been programmed.

This temperature will be maintained until the beginning of the next programmed schedule.

\*\*\*\*\*