


warmup[®]


MODEL TH115A/F/AF

VISUAL GUIDE




SETTING THE TIME AND DAY

Set the current time by using the hour and minute buttons
Set the day by using the day button



PROGRAMMING THE COMFORT (the ON temperature) AND ECONOMY (the OFF temperature) SETTINGS



COMFORT SETTING *


Preset at 21 °C for Air
and 28 °C for floor
sensing thermostats

1. Select the new temperature using the arrow keys ▲▼
2. Press the * button for approx 3 secs until the * icon is displayed

ECONOMY SETTING ☾


Preset at 18 °C for Air
and 20 °C for floor
sensing thermostats –
Recommended
temperature setting is
5 °C

1. Select the new temperature using the arrow keys ▲▼
2. Press the ☾ button for approx 3 secs until the ☾ icon is displayed



IF YOU WOULD LIKE 2 SETTINGS/DAY (ie 1 HEATING CYCLE) ON AT 7AM AND OFF AT 10PM

PRESS THE MODE BUTTON AND ENSURE THAT THE AUTOMATIC (CLOCK) ICON IS DISPLAYED




Set P1

1. Press Pgm to access the programming mode.
2. Select day – for the day to be programmed.
3. Press the hour and min buttons to set the time

Set P2

1. Press Pgm to select Program 2
2. Select day – for the day to be programmed.
3. Press the hour and min buttons to set the time
4. Mode/Ret to exit this function



CLEAR P3 AND P4

Select PGM – ensure that the program is on 3

Select the day of the week (press and hold the day button for 3 secs if you want to select all days of the week)


Press Clear

Now repeat the procedure and clear P4

IF YOU WOULD LIKE 4 SETTINGS/DAY (ie 2 HEATING CYCLES) Eg – ON AT 7AM AND OFF AT 10AM ON AGAIN AT 5PM AND OFF AT 9PM



PRESS THE MODE/RET AND ENSURE THAT THE AUTOMATIC ICON CAN BE SEEN ON THE DISPLAY



Set P1





1. Press Pgm to access the programming mode.
2. Select day – for the day to be programmed.
3. Press the hour and min buttons to set the time

Set P2



1. Press Pgm to select Program 2 or P2.
2. Select the day to be programmed.
3. Hour & min buttons - set the time






Set P3


1. Press Pgm to select Program 3 or P3.
2. Select day – for the day to be programmed.
3. Press the hour and min buttons to set the time

Set P4

1. Press Pgm to select Program 4 or P4.
2. Select day – for the day to be programmed.
3. Press the hour and min buttons to set the time
4. Mode/Ret to exit this function



IF YOU WOULD LIKE THE HEATING TO BE AT THE SAME TEMPERATURE FOR 24 HOURS






1. Press the Mode button to display the manual icon



2. Press the arrow keys ▲▼ for the desired temperature.


OR




1. Press the Mode button to display the manual icon 
2. Press either the comfort or economy buttons for the preset temperatures.

ADDITIONAL POINTS TO NOTE

IF YOU WOULD LIKE TO SWITCH OFF YOUR HEATING, MOVE THE ON/STANDBY SWITCH TO "STANDBY".





VACATION SETTING

1. Select the new temperature using the arrow keys ▲▼
2. Press the  button for approx 3 secs until the icon is displayed

ERASE YOUR PROGRAM

1. Press Pgm
2. Select day – for the day to be programmed.
3. Press Clear



RESET THE TH115

1. Press and hold ▲
2. Position switch from ON to Standby and then to ON
